


Tiny House Building Cheat



Decimal Conversations	
1/16	.0625
1/8	.125
3/16	.1875
1/4	.25
5/16	.3125
3/8	.375
7/16	.4375
1/2	.5
9/16	.5625
5/8	.625
11/16	.6875
3/4	.75
13/16	.8125
7/8	.875
15/16	.9375

Top Five Tools
Hammer
Tape Measure
Level
Square
Pencil



Time Savers
Plan Ahead
Have all materials on hand
Measure twice, cut once

Lumber Dimensions	
1x1	3/4 x 3/4
1x3	3/4 x 2 1/2
1x4	3/4 x 3 1/2
1x6	3/4 x 5 1/2
1x8	3/4 x 7 1/4
1x10	3/4 x 9 1/4
1x12	3/4 x 11 1/4
2x2	1 1/2 x 1 1/2
2x3	1 1/2 x 2 1/2"
2x4	1 1/2" x 3 1/2"
2x6	1 1/2" x 5 1/2"
2x8	1 1/2" x 7 1/4"
2x10	1 1/2" x 9 1/4"
2x12	1 1/2" x 11 1/4"
4x4	3 1/2" x 3 1/2"
4x6	3 1/2" x 5 1/2"
6x6	5 1/2" x 5 1/2"

Nails	Vs.	Screws
Stronger against side to side forces		Stronger against pulling forces
		

When nailing/screwing into treated lumber always use galvanized nails/screws. Standard fasteners, zinc coated and others can rapidly corrode in treated lumber.

